





Put the chair onto flat place, fully tight all the screws after well adjusted flatness of the chair.

