








BUNKY 90


 A Headboard 2 pcs	 B Footboard 2 pcs	 C Siderail 2 pcs
 D Center bar 2 pcs	 E Cross bar 4 pcs	 F Support legs 4 pcs
 G 1 pc	 H 1 pc	 I 4 pcs
 J 44 pcs	 K 2 pcs	 L 2 pcs
 M 3 pcs	 N 2 pcs	 O 2 pcs
 P M6*20 40 pcs	 Q M6*40 14 pcs	 R M6*45 3 pcs

HALMAR Sp. z o.o.

ul. Centralnego Okręgu Przemysłowego 2, 37-450 Stalowa Wola, POLSKA / POLAND
tel. +48 15 843 28 10, fax: +48 15 842 19 57, e-mail: office@halmar.com.pl



1/5^{v.2}

BUNKY 90


7 pcs  S M6*65	11 pcs  T M6	8 pcs  U
11 pcs  V	88 pcs  W	2 pcs  X
2 pcs  Y	4 pcs  Z	

BUNKY 90


1 x2





2 x2



3




4




BUNKY 90


5




6



7




8




BUNKY 90


9



10



11




Dla zachowania bezpieczeństwa, należy przymocować ramę łóżka do ściany, za pomocą wkrętów oraz blaszki.

Fix the inner side rail of upper layer of bed on the wall with expansion screw and U-shape fitting.


1





2




3



F



12



5/5